

wacom®

Accessories

Live. Dare. Create.



Grip Pen



Pro Pen



Standard Nibs



Wacom Pro Pen 2



Wacom Pro Pen 3D



Pro Pen 2 Standard Nibs



Pro Pen 2 Felt Nibs



Wacom Finetip Pen
(for Wacom Intuos Pro Paper Edition)



Finetip 0.4 Refill



Wacom Ballpoint Pen
(for Wacom Intuos Pro Paper Edition)



Ballpoint 1.0 Refill



Cintiq Ergo Stand
(for Cintiq 27)



Wacom Stand
(for Wacom Cintiq Pro and
Wacom MobileStudio Pro)



Tilt Stand
(for Cintiq 22)



Soft Case
(Medium and Large)



ExpressKey™ Remote



Wacom Color Manager



Wacom Wireless Keyboard



Wacom Link



Wacom Paper Clip & Case
(for Wacom Intuos Pro)



Wacom Texture Sheets
(for Wacom Intuos Pro)





Pens & Nibs

Cases

Miscellaneous

Wacom		Wacom Intuos Pro Creative Pen Tablets					Cintiq & Wacom Cintiq Pro Creative Pen Displays					Wacom MobileStudio Pro	
Accessories	Part Numbers	PTH451	PTH660	PTH660P (Paper)	PTH860	PTH860P (Paper)	DTK1301	DTH1320	DTH1620	DTK2200 DTH2200	DTK2700 DTH2700	DTHW1320	DTHW1620
Wacom Grip Pen	KP501E2	*					X			*	X		
Wacom Pro Pen	KP503E	X					*			X	*		
Wacom Pro Pen 2	KP504E		*	*	*	*		*	*			*	*
Wacom Pro Pen 3D	KP505		X	X	X	X		X	X			X	X
Standard Nibs	ACK20001	X					X			X	X		
Pro Pen 2 Standard Nibs (5 pack)	ACK22201		X	X	X	X		X	X			X	X
Pro Pen 2 Felt Nibs (5 pack)	ACK22203		X	X	X	X		X	X			X	X
Wacom Finetip Pen	KP13200D			*		*							
Wacom Ballpoint Pen	KP13300D			X		X							
Finetip .4 Refill (5 pack)	ACK22208			X		X							
Ballpoint 1.0 Refill (3 pack)	ACK22207			X		X							
Cintiq Ergo Stand	ACK411040Z										X		
Wacom MSP Stand	ACK627K											X	X
Cintiq 22 Tilt Stand	MSTA170									*			
Soft Case, medium	ACK52701		X	X			X	X				X	
Soft Case, large	ACK52702				X	X			X				X
ExpressKey™ Remote	ACK411050	X	X	X	X	X	X	X	X	X	*	X	X
Wacom Color Manager	EODIS3-DCWA						X	X	X	X	X	X	X
Wacom Wireless Keyboard	WKT400	X	X	X	X	X	X	X	X	X	X	X	X
Wacom Link	ACK42719							*	*			X	X
Wacom Paper Clip & Case	ACK42213		X	*	X	*							
Texture Sheet Med-Smooth	ACK122211		X	X									
Texture Sheet Med-Standard	ACK122212		X	X									
Texture Sheet Med-Rough	ACK122213		X	X									
Texture Sheet Large-Smooth	ACK122311				X	X							
Texture Sheet Large-Standard	ACK122312				X	X							
Texture Sheet Large-Rough	ACK122313				X	X							

Legend: X = Optional Accessory, * = Replacement Part (Included in box with main product)

Note: This is a list of the most commonly purchased accessories and replacement parts. It is not a comprehensive list.